

PROCYCLE

Questions? Call: 541-688-9543 or email: info@procycle.us

TT-R125 Jet Kit Installation Notes

Parts Supplied

- 17.5 & 20 Pilot Jets and 110 & 112.5 Main Jets

Installation Instructions

- If your TT-R is stock, start with a 17.5 Pilot Jet and a 110 Main Jet.
- If you have an aftermarket pipe, begin with a 17.5 Pilot Jet and a 110 Main Jet.
- If you have an aftermarket Air Filter and Pipe, install the 17.5 Pilot Jet and a 112.5 Main Jet.
- Adjust the Fuel Mixture Screw for the best idle.
- Should you desire a richer low end, use the 20 Pilot Jet. For a richer mid-range, move the Needle Clip to the 3rd position (from the top).
- The above recommendations are a good starting point for jetting only. Use the jet combination that makes your bike run the best!

Important: All appropriate safety equipment and gear must be used during the installation of this or any ProCycle product including any time you work on a vehicle. ProCycle accepts no responsibility for injuries or damage incurred during the installation of any products.