

# PROCYLE

Questions? Call: 541-688-9543 or email: [info@procycle.us](mailto:info@procycle.us)

## DRZ125 Jet Kit Installation Instructions

### Parts Supplied

- 20 & 22.5 Pilot Jets, 107.5 & 110 Main Jets and Needle Clip on 2<sup>nd</sup> groove with washer on top of clip.

### Installation Instructions

- If your DRZ is stock, start with a 20 Pilot Jet and a 105 Main Jet. Use the new Needle with the Clip on the 2<sup>nd</sup> groove with washer on top of Clip.
- If you have an aftermarket pipe, begin with a 20 Pilot Jet and a 107.5 Main Jet. Use the new Needle with the Clip on the 3<sup>rd</sup> groove with the washer on top of the Clip.
- For a richer top end, install the 110 Main Jet.
- The above recommendations are a good starting point for jetting only. Use the jet combination that makes your bike run the best!

**Important:** All appropriate safety equipment and gear must be used during the installation of this or any ProCycle product including any time you work on a vehicle. ProCycle accepts no responsibility for injuries or damage incurred during the installation of any products.