

PROCYCLE

Questions? Call: 541-688-9543 or email: info@procycle.us

TW200 2001-Current Jet Kit Installation Instructions

Parts Supplied

- 34 Pilot Jet
- 115, 120, 125, 130, 135 and 140 Main Jets
- 6 Shims

Installation Instructions

- From the factory, your TW most likely came with a #126 Main Jet and a #31 Pilot Jet. Yamaha has now discontinued many of the factory style jets for the TK carburetors. We have found an aftermarket Main Jet that fits the TK carb, but the numbering sequence is not the same as the Yamaha jets. Main Jet size numbers you find on the internet will not be the same as the jets we supply.
- ProCycle recommends installing the #125 Main Jet, the #34 Pilot Jet and the enclosed Jet Needle with one shim under the Needle Clip. This is a good starting point for tuning.
- Each motorcycle can run differently depending on many factors, this is why this jet kit contains more than the jets that we recommend. If you have made changes to your engine, exhaust, or intake you might require different jetting. Also, if you live at higher elevations you may also require different jetting. Our recommendations are a good starting point. Use the jet combination that makes your bike run the best.

Important: All appropriate safety equipment and gear must be used during the installation of this or any ProCycle product including any time you work on a vehicle. ProCycle accepts no responsibility for injuries or damage incurred during the installation of any products.