

HONDA Handlebar Weight Removal

Remove original handlebar end weight and internal weight parts.

1. Left side, roll back hand grip and depress the two retaining clips through the holes in the handlebar with a screwdriver. There is one top and one bottom.
2. To access holes on Right side, unscrew throttle housing and separate the two halves enough to slide the twist grip in from the end.
3. Leave handlebar weight connected to the internal weight to help with removing the internal parts.
4. Pull on weight while pressing clips through hole.
5. The above steps will leave a hollow handlebar for mounting handguard.

(see images opposite)

